










Quick Guide for Installation

TRI..., TR... Turbo Coupling with Pulley 91800265110

Note:

This guide is **not** intended to replace the installation and operating manual. It just illustrates steps required during installation of a **TRI, TR** type turbo coupling and provides reference to the installation and operating manual for full details.

<p>1)</p>  <p>Installation and Operating Manual (Translation of the original installation and operating manual) TRI... TR... Turbo Coupling with Constant Fill and Pulley Including design as per ATEX directives: Directive 94/9/EC (valid until April 19, 2016), Directive 2014/34/EU (valid from April 20, 2016)</p> <p>Version 5, 2016-01-11 3626-011200 en, Protection Class 0: public</p> <table border="1"> <tr> <td>Serial No.:</td> <td></td> </tr> <tr> <td>Coupling type:</td> <td></td> </tr> <tr> <td>Year of manufacture:</td> <td></td> </tr> <tr> <td>Mass (weight):</td> <td>1g</td> </tr> </table> <p>Read and observe the latest version of the Manual 3626-011200 before starting to work.</p>	Serial No.:		Coupling type:		Year of manufacture:		Mass (weight):	1g	<p>2)</p>  <p>Have ready the required tools (see Chapter 8.1).</p>	<p>3)</p>  <p>Check and prepare the shafts and hubs for mounting: apply lubricant (see Chapter 8.2).</p>
Serial No.:										
Coupling type:										
Year of manufacture:										
Mass (weight):	1g									
<p>4)</p>   <p>max. 150°C (302 °F)</p> <p>Recommendation: Warm up the hubs evenly to 80 °C (176 °F) (see Chapter 8.3).</p>	<p>5)</p> <p>Mounting the coupling with mounting device (Chapter 8.3.2).</p>  <p>Mounting the coupling hub (see Chapter 8.3.1).</p>	<p>6)</p> <p>Mounting of belts and belt tension: The pulleys must be in alignment during operation (Chapter 8.4).</p>  <p>Connection of bearing cover / pulley</p> <p>F_r</p> <p>h</p>								
<p>7)</p> <p>Permissible radial force F_r, as a function of the lever arm h.</p> <p>See also the diagrams in Chapter 8.4.1:</p> <p>TR..., DTR... couplings</p> 	<p>8)</p> <p>Alignment: Align the shafts(see Chapter 8.5).</p> <p>For alignment, support the motor feet using shims or foil sheets. It is advantageous to use claws for the adjusting screws on the foundation for lateral movement of the drive unit.</p> <ul style="list-style-type: none"> Align the input and output shaft with each other; the pulleys must be in alignment. Fix the input and output unit to the foundation. Check the alignment after tightening all screws, and correct it, if necessary. 	<p>9)</p> <p>Fill in the specified quantity of operating fluid:</p>  <p>(see Chapter 9 and 10).</p>								